

To access the USB and AUX inputs, you'll need to remove the MC-2 from its current position. There are four Allen screws securing the MC-2 in place. Simply remove these screws, and then pull the radio out to gain access to the USB and AUX inputs.



Before proceeding with the installation of the WWX-USB3.5, ensure that you have proper clearance for its body at the chosen location. Once the location is determined, proceed to drill a 1" hole, allowing you to easily feed the cabling through the opening.

Next, take note that the adapter's body is threaded and equipped with a nut for secure fastening. Prior to making any connections and re-mounting the MC-2, ensure that you lock the adapter's body in place using the provided nut. This will ensure a stable and secure installation of the WWX-USB3.5.



Secure the cables' slack with zip-ties and tuck them towards the back left-hand side. To prevent any rattling, you can wrap the cable bundle in felt tape.

Next, connect your USB and 3.5 Aux cables into the MC-2. For added security during use, tape or heat shrink the connections to prevent accidental unplugging while riding. Once the connections are secure, proceed to remount the unit in its original position.

