

GATORSTEP APPLICATION INSTRUCTIONS

Clean Surface



Clean the surface of the cooler making sure it's free from dust, debris, and oils of any kind. Wipe down the cooler with 99% isopropyl alcohol and let dry.

Wipe Wax Paper



Clean all the dust from the backing paper so it doesn't recontaminate the prepped surface.

Lightly Cut Backing



Use Exacto knife to lightly cut away half of the backing paper without cutting into GatorStep. This will give a section to hinge from and an easy way to properly place for final fitment. It is recommended to apply heat to back of the adhesive before sticking it down to maximize adhesion.

Rub Air Out



Use light pressure so the GatorStep doesn't warp while holding one end up will allow for a quick bubble free installation. Work one side at a time.

Apply Pressure



If you have a rubber roller, use it to apply moderate pressure to activate the pressure sensitive adhesive. If not, use hands to apply pressure.

Enjoy



Verify that the placement of the GatorStep is correct and smooth. Make sure the edges are sealed tightly and flat. This is really important to prevent the possibility of edges coming loose in the future.